

RFM Cable Manager Fill Capacity Chart

Rack VCM

Cable Type: Cat 6a

0.354" diam.

RFM Part Number	80% Fill	60% Fill	50% Fill	40% Fill	30% Fill
RFM-RVCM-B	227	170	142	114	85
RFM-RVCMG-B	360	270	225	180	135
RFM-RVCM-B-72	227	170	142	114	85
RFM-RVCMG-B-72	360	270	225	180	135
RFM-RVCM-B-48	227	170	142	114	85
RFM-RVCM-B-10	441	331	276	221	166
RFM-RVCM-B-12	530	397	331	265	199
RFM-RVCM5-48	221	166	138	110	83
RFM-RVCM8-48	353	265	221	177	132
RFM-RVCM10-48	441	331	276	221	166
RFM-RVCM-B-RWF	227	170	142	114	85
RFM-RVCM-HD6	384	288	240	192	144
RFM-RVCM-HD8	512	384	320	256	192
RFM-RVCM-HD10	640	480	400	320	240
RFM-RVCM-HD12	768	576	480	384	288
RFM-RVCM-HD6-72	384	288	240	192	144
RFM-RVCM-HD8-72	512	384	320	256	192
RFM-RVCM-HD10-72	640	480	400	320	240
RFM-RVCM-HD12-72	768	576	480	384	288
RFM-RVCM-HD6-48	384	288	240	192	144
RFM-RVCM-HD8-48	512	384	320	256	192
RFM-RVCM-HD10-48	640	480	400	320	240
RFM-RVCM-HD12-48	768	576	480	384	288
RFM-FMS-6	433	325	271	217	162
RFM-FMS-8	577	433	361	289	217
RFM-FMS-10	722	541	451	361	271
RFM-FMS-12	866	650	541	433	325
RFM-FMS-15	1083	812	677	541	406
RFM-FMS-18	1299	974	812	650	487

of Cables

of Cables

of Cables

of Cables

of Cables

Rack VCM

Cable Type: Cat 6

0.250" diam.

RFM Part Number	80% Fill	60% Fill	50% Fill	40% Fill	30% Fill
RFM-RVCM-B	456	342	285	228	171
RFM-RVCMG-B	721	541	451	361	270
RFM-RVCM-B-72	456	342	285	228	171
RFM-RVCMG-B-72	721	541	451	361	270
RFM-RVCM-B-48	456	342	285	228	171
RFM-RVCM-B-10	885	664	553	442	332
RFM-RVCM-B-12	1062	796	664	531	398
RFM-RVCM5-48	442	332	277	221	166
RFM-RVCM8-48	708	531	442	354	265
RFM-RVCM10-48	885	664	553	442	332
RFM-RVCM-B-RWF	456	342	285	228	171
RFM-RVCM-HD6	770	578	481	385	289
RFM-RVCM-HD8	1027	770	642	513	385
RFM-RVCM-HD10	1283	963	802	642	481
RFM-RVCM-HD12	1540	1155	963	770	578
RFM-RVCM-HD6-72	770	578	481	385	289
RFM-RVCM-HD8-72	1027	770	642	513	385
RFM-RVCM-HD10-72	1283	963	802	642	481
RFM-RVCM-HD12-72	1540	1155	963	770	578
RFM-RVCM-HD6-48	770	578	481	385	289
RFM-RVCM-HD8-48	1027	770	642	513	385
RFM-RVCM-HD10-48	1283	963	802	642	481
RFM-RVCM-HD12-48	1540	1155	963	770	578

RFM Cable Manager Fill Capacity Chart

Rack VCM

Cable Type: Cat 6

0.250" diam.

RFM-FMS-6	868	651	543	434	326
RFM-FMS-8	1158	868	724	579	434
RFM-FMS-10	1447	1085	905	724	543
RFM-FMS-12	1737	1303	1085	868	651
RFM-FMS-15	2171	1628	1357	1085	814
RFM-FMS-18	2605	1954	1628	1303	977
	# of Cables	# of Cables	# of Cables	# of Cables	# of Cables

Rack VCM

Cable Type: Cat 5e

0.187" diam.

RFM Part Number	80% Fill	60% Fill	50% Fill	40% Fill	30% Fill
RFM-RVCM-B	815	611	509	407	305
RFM-RVCMG-B	1289	967	806	645	483
RFM-RVCM-B-72	815	611	509	407	305
RFM-RVCMG-B-72	1289	967	806	645	483
RFM-RVCM-B-48	815	611	509	407	305
RFM-RVCM-B-10	1582	1186	989	791	593
RFM-RVCM-B-12	1898	1424	1186	949	712
RFM-RVCM5-48	791	593	494	395	297
RFM-RVCM8-48	1265	949	791	633	475
RFM-RVCM10-48	1582	1186	989	791	593
RFM-RVCM-B-RWF	815	611	509	407	305
RFM-RVCM-HD6	1376	1032	860	688	516
RFM-RVCM-HD8	1835	1376	1147	918	688
RFM-RVCM-HD10	2294	1720	1434	1147	860
RFM-RVCM-HD12	2753	2065	1720	1376	1032
RFM-RVCM-HD6-72	1376	1032	860	688	516
RFM-RVCM-HD8-72	1835	1376	1147	918	688
RFM-RVCM-HD10-72	2294	1720	1434	1147	860
RFM-RVCM-HD12-72	2753	2065	1720	1376	1032
RFM-RVCM-HD6-48	1376	1032	860	688	516
RFM-RVCM-HD8-48	1835	1376	1147	918	688
RFM-RVCM-HD10-48	2294	1720	1434	1147	860
RFM-RVCM-HD12-48	2753	2065	1720	1376	1032
RFM-FMS-6	1552	1164	970	776	582
RFM-FMS-8	2069	1552	1293	1035	776
RFM-FMS-10	2587	1940	1617	1293	970
RFM-FMS-12	3104	2328	1940	1552	1164
RFM-FMS-15	3880	2910	2425	1940	1455
RFM-FMS-18	4656	3492	2910	2328	1746
	# of Cables	# of Cables	# of Cables	# of Cables	# of Cables