General Assembly Instructions for Cage Containment

The following assembly installation instructions are for reference only. Actual parts used may differ from the ones used in this generic containment. Specific layout information and diagrams will be provided in addition to these general instructions. Item numbers used in these instructions are for reference only to this parts list. Please refer to the parts list and drawings sent with your containment unit for actual layout and part numbers.

Tools Required:

- 7/16" Deep style socket or wrench
- #2 Phillips head screwdriver
- 3/4" socket or wrench
- Tape Measure (recommended)
- Chalk Line (recommended)
- Level (recommended)

Tips For Installation:

- Review all drawings and instructions first
- Unpackage items from the box and group accordingly. Ensure all parts are accounted for (refer to parts list of the accompanied layout drawings as reference)
 - Note: Some items may already be pre-assembled
- Begin installation (if possible) at a wall in order to have a ridgid support
- Have temporary supports or multiple personnel available prior to installation as the wall may be unstable at times during assembly
- Fasten all items together but do not fully tighten all items until the very end once all cage items have been fully installed
- Ensure all columns and panels are installed level and plumb to each other before final tightening

The information contained herewithin is proprietary and confidential to **R.F.MOTE LTD.** It may not be reproduced or further disseminated, in whole or in part, without prior written consent from **R.F.MOTE LTD.**



YEARS 1966 - 2016













