STEP 1.

If equipped, remove side panels from the cabinet.

STEP 2.

Place the caster pads on an angle inside the base (aprox. 45°) and begin to turn either direction so the pad is parallel with the outside front and back of the frame and push it up tight to the inside. (See reference pic)

STEP 3.

Note: There are 2 mounting holes with nuts pressed in on each side of caster pad. (See Detail A) These nuts should align with the mounting holes in the flanges on the base once in place. (See Detail B)

STEP 4.

With the flathead hardware supplied, the caster pad should be pulled up tight to the underside base flange and screws should then be installed from the top down into the nuts in the pads.

(Make sure the screws are firmly tightened down)

STEP 5.

Repeat steps 1-4 for the other pad.

